

## Instructions on how to Re-Ink Royal Mark Pre-Inked Stamps



1. Shake the ink to be sure that it is completely mixed properly.
2. Take the cap off of the ink bottle with the proper color of ink needed.
3. Adjust the dial that allows you to lower or raise the imprint die back to having the die even with the top of the stamp frame.
4. Hold the stamp upside-down – with the impression area of the stamp pointing up.
5. Holding the ink bottle over the impression area, gently squeeze the bottle. Let a few drops of ink to fall onto the surface of the lettering.
6. Place the cap back onto the bottle.
7. In some cases it takes up to 2 - 4 hours for the ink to soak into the stamp. And in other cases with water base inks it can be immediate.
8. When done and prior to use, blot the stamp with a paper towel and adjust the dial that allows you to create an even impression. Make sure the impression is not too heavy and is not using more ink then necessary when stamping. Once you complete this your good to go.

Any questions call 714-979-1405 or email us at [Sales@HittMarking.com](mailto:Sales@HittMarking.com)